

FREE STANDING PHOTOCOPY *stands*

STANDS (Models PCS10 and PCS22)

- Can be provided with security chain and padlock to attach to the photocopier or other fixture.
- Option for direct bolting to the floor with concealed internal bolts.
- Concealed cables exit through the base.
- Coloured to match coin controller.

MODEL PC S10

Allows for free standing top coin entry controllers, avoiding attachment to the photocopier.

Particularly suited for the latest generation photocopiers with access panels on all sides.

MODEL PC S22

Free standing unit suits front coin entry controllers.

Particularly suited for modern photocopiers with access panels on all sides.

ECONOMY STAND (Model PC P10)

FLAG STAND (Model FL)

- Lower cost unit
- Can mount PC151 or PC171 central, or to the left or to the right.

POLE STAND (Model PS)

- Mounts off base forward, rear or side.
- Low cost.



PC S10



PC S22



PC P10



FL



PS

